



2881-62 in Fabric 962-01



2881-62 in Fabric 818-01

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 02/01/2024

62  
60M  
60H  
601M  
601H  
601  
60

FEATURES

Flexsteel Spring Unit



DualFlex

Back Construction



Attached

Seat Construction



Attached

Seat Cushion(s)



High-Density (HC)

Tailoring



Arm Covers

Nailhead Trim



Black Nickel (D)

PRODUCT DIMENSIONS

OVERALL

Height Width Depth

SEAT

Height Width Depth

Arm Height Open Depth Wall Clearance

Reclining Sofa  
-62

42" 84" 41" 20" 72" 22" 25" 68" 7"

Power Reclining Loveseat  
-60M

42" 60" 41" 20" 48" 22" 25" 68" 7"

Power Reclining Loveseat with Power  
Headrests  
-60H

42" 60" 41" 20" 48" 22" 25" 68" 4"

Power Reclining Loveseat with Console  
-601M

42" 72" 41" 20" 60" 22" 25" 68" 7"

Power Reclining Loveseat with Console  
& Power Headrests  
-601H

42" 72" 41" 20" 60" 22" 25" 68" 4"

Reclining Loveseat with Console  
-601

42" 72" 41" 20" 60" 22" 25" 68" 7"

Reclining Loveseat  
-60

42" 60" 41" 20" 48" 22" 25" 68" 7"

- Standard
- Optional

NOTES

Available in more than 250 fabric options  
Also available in Performance fabrics - Revolution and LiveSmart  
Removable backs allow for easy lifting and maneuvering through doorways.  
Also available without nailhead trim (2882-62)  
Power mechanism allows you to smoothly recline to any position.  
Single USB port is included on each power button control.  
Also available without nailhead trim (2882-60M)  
Also available without nailhead trim (2882-60H)  
Center console features two cup holders and a storage compartment.  
Also available without nailhead trim (2882-60)  
Power allows you to smoothly recline to any position.  
A single USB port is included on each power button control on styles with arms.  
The power control allows you to independently adjust the recline and headrest.  
A separate home button returns the headrest and footrest to their original positions with one touch.  
A USB port is included on the power control for powering electronics.  
Zero draw technology only uses power when the USB port is in use.



Power Recline  
& Headrest