



3902-51 in leather 824-30

3902-51 in Leather 577-70

Davis | 3902

| 53 51M 51H 51 50M 50H 50 | FEATURES |
|--|-----------------------|
| | Flexsteel Spring Unit |
| • | DualFlex |
| | Back Construction |
| • | Attached |
| | Seat Construction |
| • | Attached |
| | Seat Cushion(s) |
| • | High-Density (HC) |
| | |

o Optional

| PRODUCT DIMENSIONS | OVERALL | | | SEAT | | | | | |
|---|---------|-------|-------|--------|-------|-------|---------------|---------------|-------------------|
| | Height | Width | Depth | Height | Width | Depth | Arm Height | Open Depth | Wall Clearance |
| Swivel Gliding Recliner -53 | 41" | 37" | 40" | 20" | 22" | 22" | 25" | 67" | 15" |
| Power Rocking Recliner -51M | 41" | 37" | 40" | 20" | 22" | 22" | 25" | 67" | 15" |
| Power Rocking Recliner with Power Headrest -51H | 41" | 37" | 40" | 20" | 22" | 22" | 25" | 67" | 15" |
| Rocking Recliner -51 | 41" | 37" | 40" | 20" | 22" | 22" | 25" | 67" | 15" |
| Power Recliner -50M | 41" | 37" | 40" | 20" | 22" | 22" | 25" | 67" | 5" |
| Power Recliner with Power Headrest -50H | 41" | 37" | 40" | 20" | 22" | 22" | 25" | 67" | 5" |
| Recliner -50 | 41" | 37" | 40" | 20" | 22" | 22" | 25" | 67" | 5" |

NOTES

Lower the footrest by applying pressure to it in a downward motion. Lowering the footrest with the handle can damage the recliner.

Power allows you to smoothly recline to any position.

A single USB port is included on each power button control on styles with arms.

The power control allows you to independently adjust the recline and headrest.

A separate home button returns the headrest and footrest to their original positions with one touch.

A USB port is included on the power control for powering electronics.

Zero draw technology only uses power when the USB port is in use.



Power Recline & Headrest

Standard