

3904-SECTP in leather 824-11

 $F L E X S T E E L^{\circ}$

© Flexsteel Industries, Inc. | Last Updated 04/24

Rio | 3904

LEATHER

Rio | 3904

19 57M 59M 58M		FEATURES	PRODUCT DIMENSIONS	OVERALL			SEAT					
	4			Heigh	t Width	n Depth	Height	Width	Depth	Arm Height	Open Depth	Wall Clearance
		Flexsteel Spring Unit										
•		DualFlex	Armless Chair -19	42"	27"	39"	20"	27"	21"			
		Sinuous Wire										
		Back Construction	Full Wedge -23	42"	64"	39"	20"	41"	21"			
•			LAF Power Recliner -57M	42"	31"	39"	20"	24"	21"	24"	68"	5"
•	• •		Armless Power Recliner -59M	42"	26"	39"	20"	26"	21"		67"	5"
•			RAF Power Recliner -58M	42"	31"	39"	20"	24"	21"	24"	68"	5"
			Straight Console -72	42"	10"	39"	24"	9"	3"			

Standard

o Optional

NOTES

Power controls on both arms effortlessly adjust the recline, keeping you comfortable

USB charging port built into power control keeps devices powered up and ready to use

Storage console houses snacks, remotes and other personal items $% \left({{{\rm{A}}_{\rm{B}}}} \right)$

Two drink holders keep beverages close at hand

Divided back cushions cradle your neck, back and lower lumbar for enhanced comfort

Streamlined inset padded armrests have a seamless look and comfortable feel

Built to last with our patented Flexsteel DualFlex Spring System™—sturdy steel ribbons attached to flexible coils that offer a wide range of motion and durability

High-density cushions consist of a high-resiliency, high-density polyurethane foam core with a soft fiber wrap that ensures comfort as you sit and recline

Available in over 50 leather options to suit any décor

Removable back allows for easy lifting and maneuvering through doorways

Power allows you to smoothly recline to any position.

A single USB port is included on each power button control on styles with arms.



Interlocking Brackets

Interlocking brackets securely attach one sectional component to another to prevent them from separating even when reclining.

Dimensions are in inches and are subject to variance. Options are subject to change without notice. © Flexsteel Industries, Inc.


$F L E X S T E E L^{\circ}$

3904 Rio Components & Configurations

Sectionals

Components

LAF = Left-Arm-Facing RAF = Right-Arm-Facing





-19




9" | _

-57 LAF Recliner -57M LAF Power Recliner -57H LAF Power Recliner

with Power Headrest

- 31" -

39"



-58 RAF Recliner -58M RAF Power Recliner -58H RAF Power Recliner with Power Headrest




-59 Armless Recliner -59M Armless Power Recliner -59H Armless Power Recliner with Power Headrest




-72 Straight Console

Sample Configurations




Scale 1/4"=1'

Dimensions are in inches and are subject to variance. © Flexsteel Industries, Inc. 7/22 FLX-CP-FR-CC-3904



124" -31" -57H -59H -59H -59H -59H -59H -59H -59H -59H -58H



FLEXSTEEL°