



2810-51 in Fabric 962-02



2810-51 in Fabric 962-02

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 08/28/2024

53
51M
51L
51H
51
50M
50L
50H
50

FEATURES

Flexsteel Spring Unit



DualFlex

Back Construction



Attached

Seat Construction



Attached

Seat Cushion(s)



High-Density (HC)

Tailoring



Arm Covers

● Standard

○ Optional

PRODUCT DIMENSIONS

	OVERALL			SEAT			Arm Height	Open Depth	Wall Clearance
	Height	Width	Depth	Height	Width	Depth			
Swivel Gliding Recliner -53	43"	37"	42"	20"	21"	22"	26"	70"	13"
Power Rocking Recliner -51M	43"	37"	42"	20"	21"	22"	26"	70"	13"
Power Rocking Recliner with Power Headrest & Lumbar -51L	43"	37"	42"	20"	21"	22"	27"	70"	13"
Power Rocking Recliner with Power Headrest -51H	43"	37"	42"	20"	21"	22"	26"	70"	13"
Rocking Recliner -51	43"	37"	42"	20"	21"	22"	26"	70"	13"
Power Recliner -50M	43"	37"	42"	20"	21"	22"	26"	70"	8"
Power Recliner with Power Headrest & Lumbar -50L	43"	37"	42"	20"	21"	22"	27"	70"	8"
Power Recliner with Power Headrest -50H	43"	37"	42"	20"	21"	22"	26"	70"	8"
Recliner -50	43"	37"	42"	20"	21"	22"	26"	70"	8"

NOTES

Lower the footrest by applying pressure to it in a downward motion. Lowering the footrest with the handle can damage the recliner.

Power allows you to smoothly recline to any position.

A single USB port is included on each power button control on styles with arms.

The power control allows you to independently adjust the recline, headrest, and lumbar support.

A separate home button returns the headrest, footrest, and lumbar support to their original positions with one touch.

A USB port is included on the power control for powering electronics.

Zero draw technology only uses power when the USB port is in use.

The power control allows you to independently adjust the recline and headrest.

A separate home button returns the headrest and footrest to their original positions with one touch.



Power Recline, Headrest, & Lumbar



Power Recline & Headrest