

3810-51 in leather 824-74



3810-51 in leather 824-74

3810-51 in leather 824-74

FLEXSTEEL®

© Flexsteel Industries, Inc. | Last Updated 08/28/2024

Arlo | 3810

53 51M 51L 51H 51 50M 50L 50H 50	FEATURES
	Flexsteel Spring Unit
•	DualFlex
•	Back Construction Attached
	Seat Construction
•	Attached
•	Seat Cushion(s) High-Density (HC)

Standard

o Optional

PRODUCT DIMENSIONS	OVERALL			SEAT					
	Height	Width	Depth	Height	Width	Depth	Arm Height	Open Depth	Wall Clearance
Swivel Gliding Recliner -53	43"	37"	42"	20"	21"	22"	26"	70"	13"
Power Rocking Recliner -51M	43"	37"	42"	20"	21"	22"	26"	70"	13"
Power Rocking Recliner with Power Headrest & Lumbar -51L	43"	37"	42"	20"	21"	22"	27"	70"	13"
Power Rocking Recliner with Power Headrest -51H	43"	37"	42"	20"	21"	22"	26"	70"	13"
Rocking Recliner -51	43"	37"	42"	20"	21"	22"	26"	70"	13"
Power Recliner -50M	43"	37"	42"	20"	21"	22"	26"	70"	8"
Power Recliner with Power Headrest & Lumbar -50L	43"	37"	42"	20"	21"	22"	27"	70"	8"
Power Recliner with Power Headrest -50H	43"	37"	42"	20"	21"	22"	26"	70"	8"
Recliner -50	43"	37"	42"	20"	21"	22"	26"	70"	8"

NOTES

Lower the footrest by applying pressure to it in a downward motion. Lowering the footrest with the handle can damage the recliner.

Power allows you to smoothly recline to any position.

A single USB port is included on each power button control on styles with arms.

The power control allows you to independently adjust the recline, headrest, and lumbar support.

A separate home button returns the headrest, footrest, and lumbar support to their original positions with one touch.

A USB port is included on the power control for powering electronics.

Zero draw technology only uses power when the USB port is in use.

The power control allows you to independently adjust the recline and

A separate home button returns the headrest and footrest to their original positions with one touch.



Power Recline, Headrest, & Lumbar



Power Recline & Headrest